

Assembly Instructions for: Mirrors - R0078 - R0079



Instructions: Unbox unit and find hardware bag inside of box.

1 - Attach feet to mirror frame with screws provided as shown.

Note: Tilt mirror may need the side bolts tightened once in a while to make sure it stays in place.

